
How do I measure pump flow accuracy in HPLC?

Use a dry 5ml volumetric flask and a calibrated stopwatch to confirm the flow **accuracy** at 1.0 mL/minute. Note that this flow rate check is not meant to replace the typically more extensive Operational Qualification checks at several flow rates. Rather it is to document the suitability of the pump to perform various PQ Test protocols described in this kit.