

How do I minimize bacterial growth in buffers for CE - FAQ

You can keep them in a cold room and you can add a little sodium azide.

Printed from the Chrom Resource Center

MicroSolv Technology Corporation

9158 Industrial Blvd. NE, Leland, NC 28451 tel. (732) 380-8900, fax (910) 769-9435

Email: customers@mtc-usa.com

Website: www.mtc-usa.com

Date: 05-10-2024