

## How do I minimize bacterial growth in buffers for CE – $\ensuremath{\mathsf{FAQ}}$

You can keep them in a cold room and you can add a little sodium azide.

Printed from the Chrom Resource Center **MicroSolv Technology Corporation** 9158 Industrial Blvd. NE, Leland, NC 28451 tel. (732) 380-8900, fax (910) 769-9435 Email: customers@mtc-usa.com Website: www.mtc-usa.com Date: 05-06-2024