

What would you recommend to reduce time to develop an HPLC method - Tips & Suggestions

Use shorter columns, increase flow rate to 2-2.5mls / minute and find appropriate bonded or stationary phases to match your mobile phases and solubility of your analytes and consider columns that rapidly equilibrate between runs such as the Cogent TYPE- C^{TM} HPLC columns.



Printed from the Chrom Resource Center
Copyright 2024, All Rights Apply
MicroSolv Technology Corporation

9158 Industrial Blvd. NE, Leland, NC 28451 tel. (732) 380-8900, fax (910) 769-9435

Email: customers@mtc-usa.com

Website: www.mtc-usa.com