

Do the HPLC tee fitting unions require ferrules or flat bottom flangeless fittings - FAQ

These high pressure tee fittings are actually unions are used in the high pressure zones for HPLC require ferrules. Only the low pressure tee junctions require the flat bottom fittings.



47302-11

Tee, High Pressure, Standard Size,
Hand Tighten.

Click [HERE](#) for unions for HPLC ordering information and pictures

Printed from the Chrom Resource Center

MicroSolv Technology Corporation

9158 Industrial Blvd. NE, Leland, NC 28451

tel. (732) 380-8900, fax (910) 769-9435

Email: customers@mtc-usa.com

Website: www.mtc-usa.com

Date: 07-27-2024