
Do the HPLC Tee Fittings Require Ferrules or Flat-Bottom (Flangeless) Fittings? FAQ

The High Pressure Tee Fittings used in the High Pressure Zones for HPLC require Ferrules. Only the Low Pressure Tee Junctions require the Flat Bottom Fittings.



47302-11

Tee, High Pressure, Standard Size,
Hand Tighten.

[Unions for HPLC Ordering Information](#)