

The best choice is to use a column coupler to minimize dead volume and not tubing. As for the appropriate ID, you should use the same ID as in your HPLC system tubing if this is how you want to proceed.

Click [HERE](#) for column couplers ordering information and pictures.



Printed from the Chrom Resource Center

Copyright 2024, All Rights Apply

MicroSolv Technology Corporation

9158 Industrial Blvd. NE, Leland, NC 28451

tel. (732) 380-8900, fax (910) 769-9435

Email: customers@mtc-usa.com

Website: www.mtc-usa.com