

Use the table below for converting from metric to imperial and vice versa for items like tubing, union, and column coupler dimensions.

<b>Metric</b>		<b>Imperial</b>
0.13 mm	=	0.005 inches
0.18 mm	=	0.007 inches
0.25 mm	=	0.010 inches
0.30 mm	=	0.012 inches
0.40 mm	=	0.016 inches
0.50 mm	=	0.020 inches
0.75 mm	=	0.030 inches
0.80 mm	=	0.031 inches
1.0 mm	=	0.040 inches
1.5 mm	=	0.060 inches

Printed from the Chrom Resource Center

Copyright 2024, All Rights Apply

**MicroSolv Technology Corporation**

9158 Industrial Blvd. NE, Leland, NC 28451

tel. (732) 380-8900, fax (910) 769-9435

Email: [customers@mtc-usa.com](mailto:customers@mtc-usa.com)

Website: [www.mtc-usa.com](http://www.mtc-usa.com)