

**No, the guard column cartridge can be placed in the holder in either direction.**

The label on the column does not indicate a particular direction to place the column in the holder. The guard columns have no flow direction in the holder.

[Click HERE for Ordering Information Including Guard Column Holders](#)



Printed from the Chrom Resource Center

Copyright 2024, All Rights Apply

**MicroSolv Technology Corporation**

9158 Industrial Blvd. NE, Leland, NC 28451

tel. (732) 380-8900, fax (910) 769-9435

Email: [customers@mtc-usa.com](mailto:customers@mtc-usa.com)

Website: [www.mtc-usa.com](http://www.mtc-usa.com)