



## Does the direction of a guard column in the holder matter – FAQ

**No, the guard column cartridge can be placed in the holder in either direction.**

The label on the column does not indicate a particular direction to place the column in the holder. The guard columns have no flow direction in the holder.

[Click HERE for Ordering Information Including Guard Column Holders](#)



**MicroSolv Technology Corporation**  
9158 Industrial Blvd. NE, Leland, NC 28451  
tel. (732) 380-8900, fax (910) 769-9435  
Email: [customers@mtc-usa.com](mailto:customers@mtc-usa.com)  
Website: [www.mtc-usa.com](http://www.mtc-usa.com)