



## Using a water rinse when separating proteins by CE – Tips & Suggestions

It is recommended that when your samples are high concentrations of protein or simply a very “sticky” protein, that immediately before you inject the sample, between runs, that you dip your capillary in CEwater.

It is further recommended that immediately after the separation, that you dip your capillary in CEwater. This will assist in removing any protein that will stick to the outside of the capillary walls and will be injected as a type of sample carry over.

Printed from the Chrom Resource Center

**MicroSolv Technology Corporation**

9158 Industrial Blvd. NE, Leland, NC 28451

tel. (732) 380-8900, fax (910) 769-9435

Email: [customers@mtc-usa.com](mailto:customers@mtc-usa.com)

Website: [www.mtc-usa.com](http://www.mtc-usa.com)

Date: 05-19-2024