

## What is the mobile phase used in the HSQ Kit and how much is used – $\ensuremath{\mathsf{FAQ}}$

For isocratic system testing, prepare one liter of 13:87 acetonitrile:0.1% acetic acid (1mL/L).

For gradient testing, prepare 2 liters.

Click *HERE* for PQ Kit<sup>™</sup> and HSQ Kit<sup>™</sup> ordering information and pictures.

Printed from the Chrom Resource Center

MicroSolv Technology Corporation

9158 Industrial Blvd. NE, Leland, NC 28451 tel. (732) 380-8900, fax (910) 769-9435

Email: customers@mtc-usa.com

Website: www.mtc-usa.com
Date: 03-05-2024