

**The principle mechanism of removal of the polyimide coating using the MicroSolv Window Maker™ is burning it off with measured heat and without using a flame.**

By burning the polyimide at a predetermined temperature range, it can be easily removed by hand wiping the burn area with a gentle solvent such as water or acetone using a clean, non fibrous cloth or paper.

Click [HERE](#) for MicroSolv Window Maker Ordering Information

Printed from the Chrom Resource Center

Copyright 2024, All Rights Apply

**MicroSolv Technology Corporation**

9158 Industrial Blvd. NE, Leland, NC 28451

tel. (732) 380-8900, fax (910) 769-9435

Email: [customers@mtc-usa.com](mailto:customers@mtc-usa.com)

Website: [www.mtc-usa.com](http://www.mtc-usa.com)