

In the chart below,  $t_R$  is the retention time and  $t_M$  is the hold-up time.

Definition: the hold-up time is the time of an analyte (small molecule) which completely penetrates the pores and which is not retained at all by the stationary phase.

